

チェーン No.	部品 No.	チェーン長 (Links)	列数	エンジンモデル No.	自動車メーカー
EF317E	13028-97E01	86	Single	VE30DE	NISSAN
	13028-03G00	106	Single	Z24I	NISSAN
	13028-15G00	98	Single	Z16S	NISSAN
	13028-67G00/27G00	102	Single	Z20	NISSAN
	13028-77A01	92	Single	GA16I	NISSAN
	13028-53J02/53J03	124	Single	SR20DE	NISSAN
	13028-53F02	92	Single	KA24DE	NISSAN
	13028-40F01	102	Single	KA24E	NISSAN
	13028-53Y00	80	Single	GA16DE	NISSAN
	13028-53Y10	54	Single	GA16DE	NISSAN
	13028-60U00	120	Single	VH	NISSAN
	13506-66010	112	Single	1FZFE	TOYOTA
	13506-75010	102	Single	2TZFVE,1RZ-E,2RZ-E	TOYOTA
	G601-12-201	102	Single	G6	MAZDA
ES317R (06B)	13506-13020/1	56	Single	4K,2K	TOYOTA
	13506-35010/20	98	Single	21R,22R	TOYOTA
	13506-35030	96	Single	22R	TOYOTA
	0222-14-151A	46	Single	MA,NA,VC	MAZDA
	8-94201-047-1	94	Single	G180Z	ISUZU
	8-94200-948-1	92	Single	G161Z	ISUZU
	0483-23-260	90	Single	PC,TC	MAZDA
	0324-14-151	44	Single	UC	MAZDA
ES317R-2 (06B-2)	13028-10601	52	Double	J13,J15,J16	NISSAN
	13028-21000	110	Double	L16,L18,L24,L26,L28	NISSAN
	13028-N8400	102	Double	Z20	NISSAN
	13028-18001	54	Double	A12,A14,A15	NISSAN
	13028-32200	54	Double	H20,H30	NISSAN
	13028-C6000	62	Double	P40	NISSAN
	13028-10W00	106	Double	Z24	NISSAN
	13028-V0700	112	Double	LD20,LD28	NISSAN
	13506-44010	52	Double	5R	NISSAN
	13506-44010	52	Double	5R	TOYOTA
	13506-33010	62	Double	8R,18R	TOYOTA
	13506-25010	60	Double	2T,3T,2Y,3Y	TOYOTA
	13506-41010	112	Double	4M,5M	TOYOTA
	13506-22010	56	Double	3K,4K	TOYOTA
	13506-38010	98	Double	20R	TOYOTA
	0453-12-201A	100	Double	NA	MAZDA
	MD-002921	96	Double	4G32	MITSUBISHI
	MD-021230	102	Double	4G52	MITSUBISHI
	3953-12-401	90	Double	E5,UC	MAZDA
	0488-23-260	90	Double	PC,TC,UC	MAZDA
0381-23-260	106	Double	MA,VC	MAZDA	
EF05E	13506-21020	124	Single	1NZ-FE	TOYOTA
	13506-21030	120	Single	2NZ-FE	TOYOTA
	13506-22030	130	Single	1ZZ-FE,3ZZ-FE,4ZZ-FE	TOYOTA
	13506-28010/1/2	134	Single	1AZ-FE,2AZ-FE	TOYOTA
	13506-37010	140	Single	2ZR-FE	TOYOTA
	13506-37020	142	Single	3ZR-FE	TOYOTA
	13506-88600	136	Single	2ZZ-GE	TOYOTA
	13506-B1010	132	Single	3SZ-FE	TOYOTA
	13507-75010	82	Single	3ZR-FE	TOYOTA
	12761-77E11	98	Single	J20A,J18A	SUZUKI
	12762-77E00	56	Single	J20A,J18A	SUZUKI
	13506-40010	124	Single	1KR-FE	TOYOTA
	13506-23030	128	Single	2SZ-FE	TOYOTA